

# SEAT BELT WARNING SYSTEM

The **Muirhead®** Seat Belt Warning system is designed to isolate the vehicles ignition circuit to prevent the engine from starting / running whilst the operator is not wearing their seat belt (both the ignition and starter circuits can be isolated).

Normal operation resumes when the operator fastens their seat belt.

If load adjustment is required or the operator needs to briefly disembark from the machine, the engine will continue to run for 60 seconds before automatic shutdown. Normal operation resumes if the operator re-fastens their seat belt within the 60 seconds.

The **Muirhead®** Seat Belt Warning system can be customised to suit your needs.

## FEATURES & BENEFITS:

- Fits most seating systems
- Customised functions available
- Simple installation
- Made for universal applications
- Maintenance free
- Improves workplace and operator safety
- Ensures equipment operators wear their seat belts when seated

For use on all types of machinery with seat belt restraints.




Part No. 1283

Seat belt controller

Part No. 1284

Seat belt switch



Manufactured by:



### PERTH

Unit 2-5/511 Abernethy Road  
Kewdale Western Australia 6105  
Ph: +61 8 9353 6577  
Fax: +61 8 9353 6578

### KALGOORLIE

24 Percy Road  
Kalgoorlie Western Australia 6430  
Ph: +61 8 9021 1600  
Fax: +61 8 9091 4927

### MT ISA

1A Ryan Road  
Mt Isa Queensland 4825  
Ph: +61 7 4749 0233  
Fax: +61 7 4749 0232

BRISBANE OFFICE: +61 7 3880 1231 MELBOURNE OFFICE: +61 3 9545 5859

[www.rct.net.au](http://www.rct.net.au)

[sales@rct.net.au](mailto:sales@rct.net.au)

Copyright© Remote Control Technologies Pty Ltd